

KILIMANJARO

A low VOC, water-based semi-transparent reflective finish formulated with light reflective glass beads blended in a base. It dries to give a unique and stunning crystalline effect.



APPLY WITH

- Brush "6"
- Brush "4"
- Roller
- Steel Trowel



RECOMMENDED FOR

Interior surfaces only. Not suitable for use on substrates where there is contact with water, such as bathrooms, kitchen sinks and damp walls.

TRIBE

SURFACE PREPARATION

- Surface must be dry and moisture content of surface should not be more than 10% when measured with a moisture meter.
- Surfaces must be free of dirt, dust, grease, loose particles and flaking paint.
- Surface must be smooth and even to avoid see-through of surface and other imperfections should be filled with suitable wall primer.
- Sanding is recommended for new substrates to remove dirt and cement flashes.

APPLICATION

- It is highly recommended that Tribe Kilimanjaro be applied by a skilled applicator to achieve desired finish and effect.
- Apply 1 coat of Tribe Fine Primer tinted to the selected colour with a roller to obtain a uniform surface coverage.
- As Tribe Kilimanjaro is semi-transparent in nature, final colour is determined by many factors such as; application method, colour of the Tribe Fine Primer, light, and reflection of the beads.
- Allow Tribe Fine Primer to dry completely before applying the second coat.
- Recoat Tribe Fine Primer with roller and allow complete drying before applying Tribe Kilimanjaro.
- Drying time of Tribe Fine Primer shall depend on weather conditions. Ideally 4 hours would be sufficient.
- 2 coats of Tribe Kilimanjaro at the spread rate of 1m²/liter/coat are recommended to achieve desired finish and effect. Thus, a total of 2 liters per m² for the 2 coats will be required.
- Apply a thin coat of Tribe Kilimanjaro with a steel trowel.
- A series of parallel 'ridges and furrows' will be observed at this stage.
- Allow a lapse of 10 to 15 minutes to stabilize the corrugations, and then use the clean steel trowel to smoothen horizontally the first coat.
- Care should be taken to avoid formation of marks which may be caused by the trowel edges.
- However, small trowel marks will be still visible; these will be covered during recoating.
- First coat will require 15-16 hours to dry (Overnight).
- Recoat Tribe Kilimanjaro using same technique as above and allow to dry overnight.

PRECAUTIONS

- The air temperature must not be below 10°C and not higher than 35°C. Humidity must not be below 10% and not higher than 85%.
- It is recommended that the surface where products are being applied is not dry during application process, to avoid marks caused by the application tools being used.
- Touch ups are not recommended, apply from corner to corner, or from a natural cut off point to another.
- Application must be smooth after leveling to eliminate trowel marks.
- Finish can show some sign of changing color due to yellowing effect of emulsion in base coat.
- A minimum of 9 m² should be covered at one go, if the substrate is having large surface areas.

IMPORTANT TO NOTE

- Considering the nature of this product, its colour can vary slightly from batch to batch.
- Due to the application technique, the texture may also vary.

DISCLAIMER

THIS GUIDE IS BASED ON EXTENSIVE LAB TESTS AND FIELD USE. HOWEVER, IF USED UNDER UNSPECIFIED CONDITIONS AND IF APPLICATION INSTRUCTIONS ARE NOT FOLLOWED CORRECTLY, THE PERFORMANCE OF THE PRODUCT MAY DIFFER.

FOR ANY FURTHER INFORMATION PLEASE REFER TO THE TECHNICAL DATA SHEET OR CONTACT OUR TECHNICAL DEPARTMENT.

TRIBE COATINGS (MAURITIUS) LTD.
DBM INDUSTRIAL ZONE, COROMANDEL, MAURITIUS
T: +230 405 7000 FAX: +230 405 7007
INFO@TRIBECOATINGS.COM

WWW.TRIBECOATINGS.COM